

Cleaning Procedure

Any time you clean your cabinets, mild soap and water will do. A solution of two drops of soap per gallon of water should be used.

We **do not** recommend using a spray polish because of the silicon in them. It is important to look for cleaning products; wipes, liquid, etc., that have a “No Wax Formula.” Cleaning products or polishes with wax can cause a build-up on your cabinets.

As with all finishes on wood, special attention should be paid to cabinets around “wet areas.” These would include; vanities, kitchen sinks, whirlpool tubs, etc. Keeping these areas dry ensures the longest life of your new cabinets

With proper care, your new cabinetry from Tischler will last for generations.

Shelving

Long shelves in your cabinets, that hold large amounts of weight, may bow slightly. Should this occur simply flip the shelf every few months. This is unlikely to happen on shelves under 36” long.



“Discover a new level of Quality”

Member of:



Tischler Wood
401 Blattner Drive
P.O. Box 242
Avon, MN 56310

Phone: 320-356-7171
Toll Free: 1-888-356-7171
Fax: 320-356-9574
E-mail: info@tischlermn.com
www.tischlermn.com



Quality
&
Innovation

Tischler Wood

Custom Cabinets

&

Furniture

Cabinet Care and Maintenance Instructions Pamphlet

Moisture in your home.

It is important to note that the moisture level in your home will affect your new cabinets. Low moisture in the winter will cause cabinet doors to shrink. High moisture in the summer will cause the doors to swell. As this occurs, you can adjust the hinges so the doors continue to function properly. It is recommended that, if possible, a humidifier be used in the winter, and a dehumidifier in the summer. Doing this will help make your cabinets, and other furniture in your home, last for a lifetime.

Door Bumpers

As you may have noticed, there are small, clear bumpers on the backside of your new cabinet doors and drawer fronts. These bumpers reduce the noise from a closing door or drawer.

Over time they may fall off and become lost. Provided in your cabinet care package are replacement bumpers. In order for the new bumper to properly adhere to the wood, you need to clean the area before applying a new bumper.

If you need additional bumpers, please contact us and they will be provided at a minimal cost.

Hinge Adjustment

Side Adjustment

Left to right adjustment is made using the screw indicated. Note the movement and continue adjusting to the desired position. In the summer months it may be necessary to make this adjustment because of the swelling of the wood in humid air.

Depth Adjustment


To make a depth adjustment, refer to the diagram, turn the screw indicated and note the movement. Continue by adjusting to the desired position.

Height Adjustment


Height adjustments vary depending on mounting plates. Look at your plate and note the correct diagram. On models with elongated screw holes; adjustment is done by loosening the screws, sliding the door, and tightening the screws again. On models without elongated screw holes; adjustment is made by simply turning the indicated screw on the plate.

Adjustment Diagrams


Side Adjustment



Depth Adjustment



Height Adjustment



Tischler Wood

Tischler Wood

401 Blattner Drive
P.O. Box 242
Avon, MN 56310

Phone: 320-356-7171
Toll Free: 1-888-356-7171
Fax: 320-356-9574
E-mail: info@tischlermn.com

www.tischlermn.com